

Assembly Instructions for the Barber Pole Inlay Kit



Carefully twist the individual spiral pieces onto the brass tube making sure the alignment marks are all at the same end. For the last piece to fit you might have to remove the brass tube for some extra "wiggle" room. Once all 4 pieces are assembled and lined up well wrap tightly with elastic bands to eliminate any gaps, then liberally apply thinned out yellow (carpenters) glue inside and out and let dry. Once dry, sand the inside of the cylinder just enough for the brass tube to fit. Glue the brass tube inside the cylinder using 2 part epoxy. Sand the ends flush with the brass tube (don't use a barrel trimmer for this) and mount on the lathe for turning and finishing. We prefer using a CA finish on these kits but all popular finish techniques will work fine. If you have any questions regarding this or any of our inlay pen kits, e-mail me at kallenshaan@cox.net

