

(A) and (B) are for holding the fixture to the miter. To set up place left side of fixture right next to the blade, tighten the blocks A and B to the miter gage, then slide the white fixture to the blade and leave about 1/16" or whatever you want to leave on the end of your blank to sand off. Hold the white fixture and tighten the other (C) block to the inside of the right side of the white fixture. Always use the end with the hole in the U bar against the blade end. Any questions please give me a call 304-483-5342. Tim Geist

